


1/2 Waist

- Align top and under Waistband edge.
- Measure at **Top of waistband**, measure from left folded edge to center, and finish at right folded edge




Hip




1. Lay flat pants on the table. For Front with 1 or 2 pleats, similar to Flat Front Pant, flatten the pleat above of fly until hip area.
2. Put the tape measure straight across from left folded edge (A) to fly end stitch (B), then continue straight across from fly end stitch to the right folded edge (C)
3. Make sure the left and right positions, where put tape measure, are the equal (A=B)

Front Rise




1. Lay the garment flat on the table
2. Make the front rise have naturally curve shape
3. Put the tape measure from crotch (where the front and back rise intersection)
4. Measure along curve up to top of waistband

Back Rise





1. Smooth the back rise become a straight line
2. Put the tape measure from crotch(where the front and back rise joint) to the top of the waistband

Outseam



1. Lay flat the whole leg on the table.
2. Position the tape measure at the top of front waistband, along the side belt loop and walk along the side seam until the edge of bottom hem.

Bottom Hem opening



1. Lay flat leg of pant, align front and back opening
2. Put the tape measure on the top of leg from left to right on the edge of leg opening
3. Get the measurement result and double measurement.

Short - Bottom Hem opening



